



Mounting Instructions

1016, 1016200 & 1018

1. Drill 1 1/8" hole
2. Insert Charger
3. Tighten backing nut
4. Install bezel over the face of the charger (optional)